

BC-STU4b BC4

SEL2

SRC9



SRC10



SRC11



SRC12



SRC13



SRC14



SRC15



SRC16



EXTENSION SOURCE

AUX 1, AUX 2, AUX 3, AUX 4

SRC-SEL, INT-SEL, CUE 1, PGM A

AUTO

CTRL-ROOM FOLLOW

TB 0-6

PHONES 1

MONO, CUT

AUX 1, AUX 2, AUX 3, AUX 4

SRC-SEL, INT-SEL, CUE 1, PGM A

AUTO

CTRL-ROOM FOLLOW

TB 0-6

PHONES 2

MONO, CUT

AUX 1, AUX 2, AUX 3, AUX 4

SRC-SEL, INT-SEL, CUE 1, PGM A

AUTO

CTRL-ROOM FOLLOW

TB 0-6

PHONES 3

MONO, CUT

AUX 1, AUX 2, AUX 3, AUX 4

SRC-SEL, INT-SEL, CUE 1, PGM A

AUTO

CTRL-ROOM FOLLOW

TB 0-6

PHONES 4

MONO, DIM, AUTOCUT, CUT

ON VG 3, ON VG 4

dB

10, 5, 0, 5, 10, 15, 20, 25, 30, 40, 50, 60, 85, 00